



STEP 2: Install shelves.

PINS under SHELVES insert into the vertical tubes of the SIDE and CENTER FRAMES.

STEP 1: Assemble base frame.

INSERT bottom of SIDE FRAME (Left and Right) verticals into the BASE FRAME tubes.

FULLY ASSEMBLED UNIT

