




STEP 1: Assemble base frame.



The two SIDE FRAMES interconnect into the CENTER FRAME. The back vertical of the SIDE FRAMES hook into the back vertical of the CENTER FRAME.

STEP 2: Install shelves.



PINS under SHELVES insert into the vertical tubes of the SIDE and CENTER FRAMES.

FULLY ASSEMBLED UNIT

